

Assembly Information RD91 / 94 Bellows Change

Please use guide in conjunction with manual

RD91

- 1) Release grub screws in lower index ring (6)
- 2) Release grub screws that now can be seen in the body and pull assembly off, noting that this has to be carefully angled to pass the bellows.

RD94

- 3) Remove the grub screws from the body (2)
- 4) Carefully pull off the body noting that this has to be carefully angled to pass the bellows.

RD91 / RD94

- 5) On the bellows assembly, remove the clip (21)
- 6) Carefully pull the shaft out noting the top part of the shaft is bent.





